




Install Guide:

All In One Modem + Router (Model : DPC3848)

Rear of Modem:



1.) Plug in Coaxial cable to jack (or cable from wall)

2.) Plug in power cable

3.) Plug in network cable to devices such Desktop (if required)

Recommended for Xbox, Playstation , Gaming PC Ect

Wireless name and password will be found on the side of your router . Your sticker will look like this:




Wireless Name: Wireless Name
Wireless Password: Password

Do Not Press RESET BUTTON
For support please call 613-354-2056
or visit <http://www.mycando.ca>



Install Guide:

Front of Modem:



- 1.) **POWER:** Needs to be ON
- 2.) **DS :** Receiving Data - Needs to be ON SOLID
- 3.) **US :** Sending Data - Needs to be ON SOLID
- 4.) **ONLINE :** Service active—Needs to be ON SOLID
- 5.) **1-4 NETWORK :** Will flash when device plugged into rear network port 1-4
- 6.) **2.4G :** Wireless (2.4) Active— Will Flash with activity
- 7.) **5G :** Wireless (5.8) Active— Will Flash with activity
- 8.) **WPS - Disabled** - LED Off
- 9.) **MOCA** - Not applicable

For questions or support contact us:

Email:

Accounting: accounting@mycando.ca

Support: support@mycando.ca

General Inquiries: info@mycando.ca

www.mycando.ca

Napanee Office:

Phone: 613-354-2056

113 Richmond Blvd, U6

Napanee, ON

K7R-3Z8